



To install the dowels properly, we recommend to make the holes in the wall with the exact size of 6 mm diameter.

The dowel should be slightly forced with perfect adjustment.

We advise to drill an initial hole with 5 mm diameter.

The hole depth must be of 40 mm.

